



# JVC

**C-14Z**  
**C-14Z-A**(Saudi Arabia)


BASIC CHASSIS
CZ

**C-14W**  
**C-14W** (-A)(Saudi Arabia)

BASIC CHASSIS
CZ




[www.electronicrepair.net](http://www.electronicrepair.net)






Refer to the following PWB pattern. : AV TERMINAL PWB PATTERN 2-15page.




## SECAM MODULE PWB CIRCUIT DIAGRAM




## CHROMA PWB CIRCUIT DIAGRAM

Refer to the following PWB pattern. : CHROMA PWB PATTERN 2-16page.



KEY NO.	KEY NAME	KEY NO.	KEY NAME	KEY NO.	KEY NAME
1	POWER(TV)	15	3	26	▲PICTURE ADJ.
2	TV	16	DISPLAY	27	-PICTURE ADJ.
3	VIDEO	17	4	28	+PICTURE ADJ.
5	CH PRESET	18	5	29	▼PICTURE ADJ.
7	SLEEP TIMER	19	6	30	VSM
8	VSM STANDARD	21	7	31	MUTE
11	COLOR SYSTEM	22	8	32	CHANNEL V
12	MENU	23	9	33	CHANNEL A
13	1	24	0	34	VOLUME -
14	2	25	- / -	35	VOLUME +

## FUNCTION OF KEYS






## REMOTE CONTROL TRANSMITTER CIRCUIT DIAGRAMS

[RM-C470-H]

www.electronicsrepair.net

IC771  
HC-337M  
REMOTE  
RECEIVER





\* DIFFERENCES LIST

MODEL	POWER CORP
C-142	QHP4060-200.5
C-142-A	QHP7370-200K

## MAIN PWB, CRT SOCKET PWB, LINE FILTER PWB CIRCUIT DIAGRAMS


[www.electronicrepair.net](http://www.electronicrepair.net)







www.electronicrepair.net

SCZ-1001A-H2  
MAIN PWB ASS'Y.















www.electronicrepair.net



DIFFERENCES LIST


MODEL	POWER CORD
C-14W	QMP4060-200J3
C-14W(-A)	QMP77370-200J3




SCZ-1001A-H2  
MAIN PWB ASS'Y

www.electronicrepair.net

NOTES X = NO PARTS MOUNTING  
BW = BUS WIRE









**C-14W**

[www.electronicrepair.net](http://www.electronicrepair.net)

