

H
G
F
E
D
C
B
A

SC1401 N0461FJ


	VCOM	1
	VCOM	2
	GND	3
	CSCOM	4
	CSCOM	5
	GND	6
	VO	7
	V16	8
	V32	9
	V48	10
	V63	11
	GND	12
	VSH	13
	VSH	14
	VLS	15
	VLS	16
	GND	17
	R5	18
	R4	19
	R3	20
	R2	21
	R1	22
	R0	23
	GND	24
	G5	25
	G4	26
	G3	27
	G2	28
	G1	29
	G0	30
	GND	31
	B5	32
	B4	33
	B3	34
	B2	35
	B1	36
	B0	37
	GND	38
	CK	39
	GND	40
	SPIO	41
	SPOI	42
	LBR	43
	LS	44
	GND	45
	YOB18	46
	YOB17	47
	YOB16	48
	YOB15	49
	YOB14	50
	YOB13	51
	YOB12	52
	YOB11	53

2	CK			GND	1
4	GND			GND	3
6	HDCK			GND	5
8	GND			GND	7
10	SPIO			R5	9
12	SPOI			R4	11
14	LBR			R3	13
16	HG			R2	15
18	VSH			R1	17
20	VLS			R0	19
22	VCOM			GND	21
24	VCOM			G5	23
26	VO			G4	25
28	V16			G3	27
30	V32			G2	29
32	V48			G1	31
34	V63			G0	33
36	YOBIS8			GND	35
38	YOBIS7			B5	37
40	YOBIS6			B4	39
42	YOBIS5			B3	41
44	YOBIS4			B2	43
46	YOBIS3			B1	45
48	YOBIS2			B0	47
50	YOBIS1			GND	49

DUNTK9919DE01
(QPWBS9919CEZZ)

www.electronicsrepair.net

OPERATION UNIT



LED UNIT

